



Standard Terminology for Membrane Switches¹

This standard is issued under the fixed designation F2112; the number immediately following the designation indicates the year of original adoption or, in the case of revision, the year of last revision. A number in parentheses indicates the year of last reapproval. A superscript epsilon (ϵ) indicates an editorial change since the last revision or reapproval.

1. Scope

1.1 This terminology defines terms that are commonly used in the membrane switch industry.

1.2 These definitions are not mutually exclusive.

2. Terminology

actuation force—the maximum force measured prior to or including point at which contact closure is achieved on a membrane switch.

bend—to force from a straight form into different and especially a curved one.

bend cycle—a fold of a sample around a specified mandrel which is “rolled” in one direction, followed by rolling in the opposite direction, returning the sample to its original position.

circuit resistance—electrical resistance as measured between two test points whose internal contacts, when held closed, complete a circuit.

conductor resistance—the measured electrical resistance through a circuit loop between two test points.

contact bounce—intermittent contact opening and contact closure that may occur after switch operation.

contact closure—the event at which a specified resistance is achieved on a membrane switch.

contact force—the force at contact closure.

crease—a ridge or groove made by folding and pressing.

crease cycle—a 180 degree crease followed by a flattening of the crease.

current carrying capacity—the maximum level of electrical current that a circuit can conduct without sustaining damage.

¹ This terminology is under the jurisdiction of ASTM Committee F01 on Electronics and is the direct responsibility of Subcommittee F01.18 on Membrane Switches.

Current edition approved Feb. 1, 2011. Published March 2011. Originally approved in 2001. Last previous edition approved in 2002 as F2112-02. DOI: 10.1520/F2112-02R11.

dielectric withstand voltage—the maximum voltage a dielectric can withstand in a membrane switch without a visual change from a voltage discharge or specified change of insulation resistance, or both.

duty cycle—the ratio of switch closed time to total cycle time.

graphic layer—optional decorated layer of a membrane switch. See Fig. 1.

insulation resistance—the electrical resistance between two isolated test points on a membrane switch.

leakage current—current flow through the insulation between test points.

membrane layer—a flexible dynamic layer which carries one or both switch poles the deflection of which is used to short both poles together. The membrane layer is a required component of a membrane switch. See Fig. 1.

membrane switch—a momentary switching device in which at least one contact is on, or made of, a flexible substrate.

membrane switch flex tail—flexible portion of a membrane switch used for input/output connection.

non-tactile switch—a switch assembly that has a tactile ratio equal to zero.

open circuit resistance—minimum allowable resistance as measured between two test points that, if lower than, will indicate an electrical short.

power capacity—electrical power is defined as current \times voltage = $V \times I$ (watts)

rigid layer—provides mechanical support for the membrane switch. See Fig. 1.

silver migration—a process by which silver, when in contact with insulating materials under electrical potential, is removed ionically from its original location, and is redeposited as a metal (silver dendrite) at some other location.

spacer layer—a material (usually dielectric) sometimes used to maintain a separation between the membrane layer and static layer of a membrane switch.

specified circuit resistance—maximum allowable circuit resistance as measured between two terminations whose internal contacts, when held closed, complete a circuit.




FIG. 1 Six Basic Layers of a Membrane Switch (Layers are shown as separate components but some can be combined into one layer. For example a graphic layer can also be the membrane layer. A second example is the tactile layer can also be the membrane layer.)

static layer—a mechanically supported layer which carries one or both poles of the switch or is used to short both poles together. The static layer is a required component of a membrane switch. See Fig. 1.

tactile layer—optional feature incorporated into a membrane switch to alter the tactile response. See Fig. 1.

tactile response—a physical sensation caused by a sudden collapse and/or snapback of a membrane switch.

tactile switch—a switch assembly that provides a tactile ratio greater than zero.

test points—two preselected conductive points in a circuit loop, possibly including a switch.

travel—measured distance of movement when a membrane switch is depressed.

ASTM International takes no position respecting the validity of any patent rights asserted in connection with any item mentioned in this standard. Users of this standard are expressly advised that determination of the validity of any such patent rights, and the risk of infringement of such rights, are entirely their own responsibility.

This standard is subject to revision at any time by the responsible technical committee and must be reviewed every five years and if not revised, either reapproved or withdrawn. Your comments are invited either for revision of this standard or for additional standards and should be addressed to ASTM International Headquarters. Your comments will receive careful consideration at a meeting of the responsible technical committee, which you may attend. If you feel that your comments have not received a fair hearing you should make your views known to the ASTM Committee on Standards, at the address shown below.

This standard is copyrighted by ASTM International, 100 Barr Harbor Drive, PO Box C700, West Conshohocken, PA 19428-2959, United States. Individual reprints (single or multiple copies) of this standard may be obtained by contacting ASTM at the above address or at 610-832-9585 (phone), 610-832-9555 (fax), or service@astm.org (e-mail); or through the ASTM website (www.astm.org). Permission rights to photocopy the standard may also be secured from the Copyright Clearance Center, 222 Rosewood Drive, Danvers, MA 01923, Tel: (978) 646-2600; http://www.copyright.com/