Road vehicles —
Measurement methods
for exhaust gas
emissions during
inspection or
maintenance

 $ICS\ 13.040.50;\ 43.060.20$ 



#### National foreword

This British Standard reproduces verbatim ISO 3929:2003 and implements it as the UK national standard.

The UK participation in its preparation was entrusted to Technical Committee MCE/22, Engines for road vehicles, which has the responsibility to:

- aid enquirers to understand the text;
- present to the responsible international/European committee any enquiries on the interpretation, or proposals for change, and keep the UK interests informed;
- monitor related international and European developments and promulgate them in the UK.

A list of organizations represented on this committee can be obtained on request to its secretary.

#### **Cross-references**

The British Standards which implement international publications referred to in this document may be found in the *BSI Catalogue* under the section entitled "International Standards Correspondence Index", or by using the "Search" facility of the *BSI Electronic Catalogue* or of British Standards Online.

This publication does not purport to include all the necessary provisions of a contract. Users are responsible for its correct application.

Compliance with a British Standard does not of itself confer immunity from legal obligations.

#### Summary of pages

This document comprises a front cover, an inside front cover, the ISO title page, pages ii to iv, pages 1 to 6, an inside back cover and a back cover.

The BSI copyright notice displayed in this document indicates when the document was last issued.

#### Amendments issued since publication

This British Standard was published under the authority of the Standards Policy and Strategy Committee on 5 November 2003

© BSI 5 November 2003

	Amd. No.	Date	Comments
•			
•			

ISBN 0 580 42889 3

# INTERNATIONAL STANDARD

BS ISO 3929:2003 ISO 3929

Third edition 2003-09-01

# Road vehicles — Measurement methods for exhaust gas emissions during inspection or maintenance

Véhicules routiers — Méthodes de mesure des émissions gazeuses au cours des inspections ou de la maintenance



Contents		Page	
Fore	eword		
1	Scope		
2	Normative references	1	
3	Terms and definitions		
4	Instrumentation	2	
5	Check, maintenance periodicity and precautions for use of instruments	2	
6	General vehicle verification		
7	Normal conditioning of vehicle		
8	Measured value corrections	4	
9	Measurement methods for exhaust gas emission		
Bibli	liography	6	

#### **Foreword**

ISO (the International Organization for Standardization) is a worldwide federation of national standards bodies (ISO member bodies). The work of preparing International Standards is normally carried out through ISO technical committees. Each member body interested in a subject for which a technical committee has been established has the right to be represented on that committee. International organizations, governmental and non-governmental, in liaison with ISO, also take part in the work. ISO collaborates closely with the International Electrotechnical Commission (IEC) on all matters of electrotechnical standardization.

International Standards are drafted in accordance with the rules given in the ISO/IEC Directives, Part 2.

The main task of technical committees is to prepare International Standards. Draft International Standards adopted by the technical committees are circulated to the member bodies for voting. Publication as an International Standard requires approval by at least 75 % of the member bodies casting a vote.

Attention is drawn to the possibility that some of the elements of this document may be the subject of patent rights. ISO shall not be held responsible for identifying any or all such patent rights.

ISO 3929 was prepared by Technical Committee ISO/TC 22, *Road vehicles*, Subcommittee SC 5, *Engine tests*.

This third edition cancels and replaces the second edition (ISO 3929:1995), which has been technically revised.

# Road vehicles — Measurement methods for exhaust gas emissions during inspection or maintenance

#### 1 Scope

This International Standard specifies methods for the direct measurement of the concentration of exhaust gas emissions from road vehicles during inspection or maintenance. It is applicable to vehicles having a maximum authorized total mass (ISO-M08, as defined in ISO 1176) not exceeding 3,5 t, equipped with controlled ignition engines, but excluding those supplied with a fuel/oil mixture (with or without automatic mixer). The methods can be used, either totally or partially, for

- periodic inspections in official garages,
- official roadside checks (e.g. by police), and
- maintenance and diagnostic operations.

#### 2 Normative references

The following referenced documents are indispensable for the application of this document. For dated references, only the edition cited applies. For undated references, the latest edition of the referenced document (including any amendments) applies.

ISO 3930/OIML R 99<sup>1)</sup>, Instruments for measuring vehicle exhaust emissions

ISO 16247<sup>2)</sup>, Road vehicles — Detection of exhaust system leaks — Helium test method and detection device specification

#### 3 Terms and definitions

For the purposes of this document, the following terms and definitions apply.

## 3.1 idle speed rotational frequency engine rotational frequency with

- fuel system controls (accelerator, choke, etc.) non-operative,
- the gearshift lever in neutral and the clutch engaged for vehicles with manually operated or semiautomatic transmission,
- the gear selector in neutral or park for vehicles with automatic transmission, and
- accessories and optional equipment that modify the rotational frequency used in accordance with the manufacturer's recommendations or regulatory requirements
- 1) Joint ISO/OIML (International Organization of Legal Metrology) document.
- 2) To be published.

#### 3.2

#### accelerated idle speed rotational frequency

engine rotational frequency specified by the manufacturer or regulatory requirements with

- fuel system controls (accelerator, choke, etc.) in the position to run at accelerated idle,
- the gearshift lever in neutral and the clutch engaged for vehicles with manually operated or semiautomatic transmission,
- the gear selector in neutral or park for vehicles with automatic transmission, and
- accessories and optional equipment that modify the rotational frequency used in accordance with the manufacturer's recommendations or regulatory requirements

#### 3.3

#### exhaust emission treatment system

additional device intended to reduce the exhaust emission level

#### 4 Instrumentation

- **4.1 Analyser** in accordance with ISO 3930/OIML R 99, suitable for the concentrations of exhaust gas emission from the vehicle under test.
- **4.2** Engine oil temperature meter in the sump or lubricant reservoir with a measurement accuracy of at least  $\pm$  2 K between 343 K and 373 K. Readings outside this range shall also be possible.
- **4.3** Pulse revolution counter for measuring engine rotational frequency. Under control conditions the measurement accuracy shall be at least  $\pm$  20 min<sup>-1</sup> between 600 min<sup>-1</sup> and 1 000 min<sup>-1</sup>, and  $\pm$  50 min<sup>-1</sup> outside this range.
- **4.4** Ambient temperature meter with a measurement accuracy of at least  $\pm$  2 K between 278 K and 313 K.

#### 5 Check, maintenance periodicity and precautions for use of instruments

#### 5.1 Check before use

The power supply to the instruments shall conform to the manufacturer's specifications.

Check that the instruments are ready for testing according to the manufacturer's operating instructions given in the owner's handbook or, at least,

- at the beginning of a day of tests,
- when the ambient conditions have changed, or
- at the beginning of the tests at each new test site, in the case of official roadside checks.

For the analyser, perform the zero and span calibration check with reference gases or using electronic or electromechanical methods (see ISO 3930/OIML R 99).

#### 5.2 Maintenance periodicity

All periodical checks shall be carried out in accordance with national regulations.

Maintenance shall be carried out in accordance with the manufacturer's instructions. Operations shall be recorded.

#### 5.3 Precautions for use

The working area shall be a firm, horizontal surface. Ambient conditions shall be in accordance with ISO 3930/OIML R 99.

The working area shall not be directly exposed to

- rain, snow or sunlight,
- interfering vibration,
- a corrosive and/or polluted atmosphere which might influence the measurement results, or
- electromagnetic interference that might influence measurement results.

#### 6 General vehicle verification

The exhaust system of the vehicle shall be leak-proof. Verify this condition in accordance with ISO 16247 or by sealing the exhaust pipe outlet while the engine is idling. No significant leakage of exhaust gases from pipe connections shall be found.

All accessories and optional equipment that modify the rotational frequency to the required different speeds shall be used in accordance with the manufacturer's recommendations or regulatory requirements.

#### 7 Normal conditioning of vehicle

#### 7.1 Warming up

The engine shall have attained normal thermal conditions, i.e. the temperature attained by the engine and its drive-line after running at least 15 min under normal urban traffic conditions over a minimum of 5 km or in accordance with manufacturer's specifications. A minimum lubricant temperature of 353 K in the sump or the lubricant reservoir shall be achieved.

#### 7.2 Test conditions

The choke shall be non-operative or no longer operative.

The air inlet ductwork shall be positioned in accordance with the manufacturer's instructions.

The oil sump dipstick hole shall be blocked during exhaust gas emission measurements.

The vehicle shall be located on a substantially horizontal site.

The sampling probe shall be inserted at least 300 mm into the exhaust outlet pipe. If the exhaust pipe shape does not allow such insertion, an exhaust extension pipe shall be provided.

In the case of several exhaust pipes, these shall be connected in a single outlet unless specified otherwise by the manufacturer. If this type of connection is not practicable, the arithmetic average of the concentration values, measured at each outlet, shall be used. In all cases, the device exhaust adaptor used shall not influence engine running.

Any disconnectable fan shall be stationary.

#### 8 Measured value corrections

For an engine fitted with a secondary air injection system, CO and HC emission measurements shall be corrected in accordance with national requirements.

#### 9 Measurement methods for exhaust gas emission

## 9.1 Vehicles without exhaust emission treatment systems or with non-controlled exhaust emission treatment systems

See Table 1.

**9.2 Vehicles with controlled exhaust emission treatment systems** (checking in the context of Directive 92/55/EEC<sup>[2]</sup>)

See Table 2.

Table 1 — Vehicles without exhaust emission treatment systems or with non-controlled exhaust emission treatment system

Step	Step Operations		Time lapse			
1	Warm up the vehicle in accordance with 7.1.		See 7.1			
2	Equip the vehicle with  — a revolution counter (see 4.3);  — a lubricant temperature meter (see 4.2), and  — an exhaust extension pipe, if necessary.  Select the highest analyser scale (see 4.1).	I	_			
3	Warm up the motor in accordance with the manufacturer's specifications or at 3 000 min <sup>-1</sup> $\pm$ 100 min <sup>-1</sup> , then go to idle speed.	60 s		- ≤ 4 min	≤ 6 min	
4	Put the analyser in measurement mode.		15 s			
5	Insert the probe into the exhaust pipe or its extension.	10 s	15.5			
6	Check that the appropriate scale has been selected and change if necessary.					
7	Over sufficient time but not exceeding 30 s, carry out the measurements to obtain minimum and maximum values. Calculate the arithmetic mean of these two values. If the result is printed, print the mean value.	≼ 30 s	_			
8	If one step fails, repeat steps 3 to 7.	_				

Table 2 — Vehicles with controlled exhaust emission treatment systems

Step	tep Operations		Time lapse			
1	Warm up the vehicle in accordance with 7.1.		See 7.1			
2	Equip the vehicle with  — a revolution counter (see 4.3),  — a lubricant temperature meter (see 4.2), and  — an exhaust extension pipe, if necessary.  Select the highest analyser scale (see 4.1).	_				
3	Condition the motor in accordance with the manufacturer's specifications or at 3 000 min $^{-1}$ $\pm$ 100 min $^{-1}$ , then go to the accelerated idle speed, which shall be at least equal to 2 000 min $^{-1}$ .		≤ 4 min	c 6 min		
4	Put the analyser in measurement mode.	10 s		≤ 6 min		
5	Insert the probe into the exhaust pipe or its extension.					
6	Check that the appropriate scale has been selected and change if necessary.					
7	Over sufficient time but not exceeding 30 s, carry out the measurements to obtain minimum and maximum values. Calculate the arithmetic mean of these two values. If the result is printed, print the mean value.	40 s				
8	If one step fails or if the result is greater than the specified limit values, repeat steps 3 to 7.		_			
9	Go to idle speed.					
10	Check that the appropriate scale has been selected and change if necessary.		≤ 2 min	_		
11	Over sufficient time but not exceeding 30 s, carry out the measurements to obtain minimum and maximum values. Calculate the arithmetic mean of these two values. If the result is printed, print the mean value obtained in phase 7 and phase 11.	40 s				
12	If one step fails, repeat steps 3, 9,10 and 11.	step fails, repeat steps 3, 9,10 and 11.				

### **Bibliography**

- [1] ISO 1176, Road vehicles Masses Vocabulary and codes
- [2] Council Directive 92/55/EEC of 22 June 1992 amending Directive 77/143/EEC on the approximation of the laws of the Member States relating to roadworthiness tests for motor vehicles and their trailers (exhaust emissions)

### **BSI** — British Standards Institution

BSI is the independent national body responsible for preparing British Standards. It presents the UK view on standards in Europe and at the international level. It is incorporated by Royal Charter.

#### Revisions

British Standards are updated by amendment or revision. Users of British Standards should make sure that they possess the latest amendments or editions.

It is the constant aim of BSI to improve the quality of our products and services. We would be grateful if anyone finding an inaccuracy or ambiguity while using this British Standard would inform the Secretary of the technical committee responsible, the identity of which can be found on the inside front cover. Tel: +44 (0)20 8996 9000. Fax: +44 (0)20 8996 7400.

BSI offers members an individual updating service called PLUS which ensures that subscribers automatically receive the latest editions of standards.

#### **Buying standards**

Orders for all BSI, international and foreign standards publications should be addressed to Customer Services. Tel: +44 (0)20 8996 9001. Fax: +44 (0)20 8996 7001. Email: orders@bsi-global.com. Standards are also available from the BSI website at <a href="http://www.bsi-global.com">http://www.bsi-global.com</a>.

In response to orders for international standards, it is BSI policy to supply the BSI implementation of those that have been published as British Standards, unless otherwise requested.

#### Information on standards

BSI provides a wide range of information on national, European and international standards through its Library and its Technical Help to Exporters Service. Various BSI electronic information services are also available which give details on all its products and services. Contact the Information Centre. Tel: +44 (0)20 8996 7111. Fax: +44 (0)20 8996 7048. Email: info@bsi-global.com.

Subscribing members of BSI are kept up to date with standards developments and receive substantial discounts on the purchase price of standards. For details of these and other benefits contact Membership Administration.

Tel: +44 (0)20 8996 7002. Fax: +44 (0)20 8996 7001.

Email: membership@bsi-global.com.

Information regarding online access to British Standards via British Standards Online can be found at <a href="http://www.bsi-global.com/bsonline">http://www.bsi-global.com/bsonline</a>.

Further information about BSI is available on the BSI website at <a href="http://www.bsi-global.com">http://www.bsi-global.com</a>.

#### Copyright

Copyright subsists in all BSI publications. BSI also holds the copyright, in the UK, of the publications of the international standardization bodies. Except as permitted under the Copyright, Designs and Patents Act 1988 no extract may be reproduced, stored in a retrieval system or transmitted in any form or by any means — electronic, photocopying, recording or otherwise — without prior written permission from BSI.

This does not preclude the free use, in the course of implementing the standard, of necessary details such as symbols, and size, type or grade designations. If these details are to be used for any other purpose than implementation then the prior written permission of BSI must be obtained.

Details and advice can be obtained from the Copyright & Licensing Manager. Tel: +44 (0)20 8996 7070. Fax: +44 (0)20 8996 7553. Email: copyright@bsi-global.com.

BSI 389 Chiswick High Road London W4 4AL