



Standard Practice for Calibrating Oil Spill Dispersant Application Equipment Boom and Nozzle Systems¹

This standard is issued under the fixed designation F1460; the number immediately following the designation indicates the year of original adoption or, in the case of revision, the year of last revision. A number in parentheses indicates the year of last reapproval. A superscript epsilon (ϵ) indicates an editorial change since the last revision or reapproval.

1. Scope

1.1 This practice covers uniform procedures for determining and reporting the dosage rate of oil spill dispersant application equipment.

1.2 This practice is applicable to spray systems employing booms and nozzles and is not fully applicable to other systems such as fire monitors, sonic distributors, or fan-spray guns.

1.3 This practice is applicable to systems for use on ships or boats and helicopters or airplanes.

1.4 This practice is one of four related to dispersant application systems using booms and nozzles. One is on design, one on calibration, one on deposition, and one on the use of the systems. Familiarity with all four standards is recommended.

1.5 *This standard does not purport to address all of the safety concerns, if any, associated with its use. It is the responsibility of the user of this standard to establish appropriate safety and health practices and determine the applicability of regulatory limitations prior to use.*

2. Referenced Documents

2.1 *ASTM Standards*:²

F1413 Guide for Oil Spill Dispersant Application Equipment: Boom and Nozzle Systems

3. Significance and Use

3.1 This practice will enable calibration of oil spill dispersant application equipment and ensure a desired dosage and uniformity across the swath width.

3.2 The data provided by the methods described herein will permit the preparation of a chart relating delivery rate with

¹ This practice is under the jurisdiction of ASTM Committee F20 on Hazardous Substances and Oil Spill Response and is the direct responsibility of Subcommittee F20.13 on Treatment.

Current edition approved April 1, 2013. Published July 2013. Originally approved in 1993. Last previous edition approved in 2007 as F1460 – 07. DOI: 10.1520/F1460-07R13.

² For referenced ASTM standards, visit the ASTM website, www.astm.org, or contact ASTM Customer Service at service@astm.org. For *Annual Book of ASTM Standards* volume information, refer to the standard's Document Summary page on the ASTM website.

application vehicle speed, flow meter reading or pump setting so that in actual application, the desired dosage will be achieved.

3.3 This practice will ensure that a dispersant application system is functional, capable of delivering a specified dosage, and that major components are operational. This will also ensure that the unit is functioning according to design specifications as detailed in Guide **F1413**.

4. Apparatus and Materials

4.1 *Pails*—of capacity 7 to 20 L (2 to 5 U.S. gal) to catch the spray from the nozzles.

4.2 *Graduated Cylinder*— of capacity 7 to 20 L or a scale having capacity of at least 20 kg (45 lbs) to determine the amount of fluid in each pail. Commercial equipment with an accuracy of at least 1 % is adequate.

4.3 *Stopwatch*.

4.4 *Test Fluid*—Water can be used as a test fluid if the viscosity of the dispersant to be used is not dissimilar to the viscosity of water. A surrogate fluid should be used if the viscosity difference is greater than approximately 100 times that of water. This can occur with more viscous dispersants or at low temperatures. The surrogate fluid could be water with the appropriate amount of thickener.

4.5 A continuing supply of water or test fluid, enough to run the system during the test period, must be available. Tank truck quantities may be required.

4.6 *Auxiliary Power Units*, where required.

4.7 *Thermometer*, to measure the temperature of test fluid.

4.8 *Flowmeter*—A flowmeter should be incorporated into the delivery system to measure the total flow out to the booms and nozzles.

5. Calibration Procedure

5.1 *Synopsis*—The calibration procedure is done in four steps. The first step is equipment inspection. Any defects are corrected before further calibration. The second step is the calibration of the flow meter. The third step is calibration of the unit by catching water spray from each nozzle. The fourth step is the preparation of a calibration curve.

5.2 *Equipment Setup*— Place the application equipment at a suitable outdoor location and close to a supply of water or test fluid. Set up the equipment in accordance with the manufacturer's instructions and inspect visually. Start the unit. All nozzles should visually be producing approximately the same amount of spray. Inoperative nozzles or other elements such as pressure gages or flow meters, are repaired or replaced before proceeding. The operation of pressure gages should be verified before proceeding.

5.3 *Dispersant Flow Meter Calibration:*

5.3.1 Calibrate the flow meter using a surrogate fluid. This surrogate fluid could be water or a surrogate fluid, if necessary. The withdrawal of test fluid from a calibrated vessel is timed to establish the flow rate. The calibration is done at a minimum of three flow rates and these should be chosen to represent typical minimum, average, and maximum dispersant flow rates.

5.3.2 Fill the calibrated vessel with test fluid and connect the dispersant input line to it. Set the desired flow rate and start the unit. After a steady flow rate is established, begin the measurement. The measurement period should be sufficiently long to allow for accurate measurements. Operate the spray system with all sub-systems and nozzles to ensure that the pressure drop across the flow meter is the same as during normal operations.

5.3.3 Run the test at least three times for each of the flow rates and the numbers averaged for each flow rate. Data are used to produce a calibration chart for the flow rate.

5.4 *Nozzle Calibration:*

5.4.1 Calibrate the apparatus using water or a surrogate test fluid, if necessary, which is collected to establish flow rates. Start the unit, and when pressure and flow are constant, catch the output from each nozzle under test using pails manipulated by test personnel at the same time. A timekeeper should give start and stop signals and maintain records of the time elapsed during collection of the fluid. Each run should last 30 to 60 s or long enough to fill one-half to two-thirds of the collection pail. All nozzles must be tested. Any number of nozzles can be tested at a time, but during any test all nozzles must be running.

5.4.2 Determine the amount of fluid in each pail by weighing it and converting to volume, or by using a calibrated cylinder. Each pail should be numbered and pre-weighed (if weight is the system used for volume determination) before the run begins. Determine the amount of fluid sprayed from each nozzle immediately after collection. Compare the amount of fluid produced by each nozzle to the calculated amount determined by taking the total flow divided by the number of

nozzles. Total flow is the sum of the fluid collected from all the nozzles. The output of each nozzle should be within 10 % of the calculated average or designed amount. If not, the nozzles should be repaired or replaced and the calibration procedure repeated. Separate calibrations must be done for each variation of pressure, number of operating nozzles, or type of nozzles.

5.5 *Calibration of Dispersant Addition (Eductor or Pump) Systems*—Boat and ship systems sometimes apply dispersant mixed with water. Addition systems are of two types, eductors and pumps. Both pumps and eductors are calibrated by measuring the volume of dispersant surrogate added to the water stream. The systems are calibrated in the configuration they are normally used. Calibrations are performed for each water pressure and water flow rate that would be used in actual practice.

5.5.1 Eductor systems are cleaned and repaired (if necessary) prior to calibration. Eductors require frequent maintenance, cleaning, and calibration. Eductors are calibrated by placing the suction tube into a calibrated cylinder and timing the withdrawal of material. Either the relative change per unit time of the water or the dispersant to be used is recorded over at least three flow settings to produce a calibration chart.

5.5.2 Dispersant addition pumps are calibrated by measuring the flow input or output with a calibrated cylinder or by weight. Tests are run at three pump settings representing a minimum, a maximum, and one or more typical operating-flow-rate setting.

5.6 *Calibration Frequency*—Systems should be calibrated at least once a year. Systems should be cleaned and re-calibrated after each use and after making system configuration changes.


5.7 *Report of Calibration Procedure*—Perform the calibration of the application system at three or more different equipment settings to produce an overall dispersant delivery chart and a flow meter correction chart.

6. Data Reporting

6.1 Data shall be accurate to two significant figures. Tables or graphs are prepared showing dispersant delivery rate in L/min (or U.S. gal/min) with pump settings and flow meter data.

7. Keywords

7.1 boom and nozzles; dispersant application; dispersant spray equipment; dispersants; oil spill chemicals; oil spill dispersants; oil spill treating agents

 **F1460 – 07 (2013)**

ASTM International takes no position respecting the validity of any patent rights asserted in connection with any item mentioned in this standard. Users of this standard are expressly advised that determination of the validity of any such patent rights, and the risk of infringement of such rights, are entirely their own responsibility.

This standard is subject to revision at any time by the responsible technical committee and must be reviewed every five years and if not revised, either reapproved or withdrawn. Your comments are invited either for revision of this standard or for additional standards and should be addressed to ASTM International Headquarters. Your comments will receive careful consideration at a meeting of the responsible technical committee, which you may attend. If you feel that your comments have not received a fair hearing you should make your views known to the ASTM Committee on Standards, at the address shown below.

This standard is copyrighted by ASTM International, 100 Barr Harbor Drive, PO Box C700, West Conshohocken, PA 19428-2959, United States. Individual reprints (single or multiple copies) of this standard may be obtained by contacting ASTM at the above address or at 610-832-9585 (phone), 610-832-9555 (fax), or service@astm.org (e-mail); or through the ASTM website (www.astm.org). Permission rights to photocopy the standard may also be secured from the ASTM website (www.astm.org/COPYRIGHT/).