

BS EN 15185:2011



BSI Standards Publication

Furniture — Assessment of the surface resistance to abrasion

NO COPYING WITHOUT BSI PERMISSION EXCEPT AS PERMITTED BY COPYRIGHT LAW

raising standards worldwide™



National foreword

This British Standard is the UK implementation of EN 15185:2011. It supersedes DD CEN/TS 15185:2005 which is withdrawn.

The UK participation in its preparation was entrusted to Technical Committee FW/0/1, Common Test Methods for Furniture.

A list of organizations represented on this committee can be obtained on request to its secretary.

This publication does not purport to include all the necessary provisions of a contract. Users are responsible for its correct application.

© BSI 2011

ISBN 978 0 580 68630 6

ICS 97.140

Compliance with a British Standard cannot confer immunity from legal obligations.

This British Standard was published under the authority of the Standards Policy and Strategy Committee on 31 May 2011.

Amendments issued since publication

Date	Text affected
------	---------------

EUROPEAN STANDARD

EN 15185

NORME EUROPÉENNE

EUROPÄISCHE NORM

May 2011

ICS 97.140

Supersedes CEN/TS 15185:2005

English Version

Furniture - Assessment of the surface resistance to abrasion

Ameublement - Évaluation de la résistance de la surface à l'abrasion

Möbel - Bewertung der Abriebfestigkeit von Oberflächen

This European Standard was approved by CEN on 24 March 2011.

CEN members are bound to comply with the CEN/CENELEC Internal Regulations which stipulate the conditions for giving this European Standard the status of a national standard without any alteration. Up-to-date lists and bibliographical references concerning such national standards may be obtained on application to the CEN-CENELEC Management Centre or to any CEN member.

This European Standard exists in three official versions (English, French, German). A version in any other language made by translation under the responsibility of a CEN member into its own language and notified to the CEN-CENELEC Management Centre has the same status as the official versions.

CEN members are the national standards bodies of Austria, Belgium, Bulgaria, Croatia, Cyprus, Czech Republic, Denmark, Estonia, Finland, France, Germany, Greece, Hungary, Iceland, Ireland, Italy, Latvia, Lithuania, Luxembourg, Malta, Netherlands, Norway, Poland, Portugal, Romania, Slovakia, Slovenia, Spain, Sweden, Switzerland and United Kingdom.



EUROPEAN COMMITTEE FOR STANDARDIZATION
COMITÉ EUROPÉEN DE NORMALISATION
EUROPÄISCHES KOMITEE FÜR NORMUNG

Management Centre: Avenue Marnix 17, B-1000 Brussels

Contents

Page

Foreword.....	3
1 Scope	3
2 Normative references	3
3 Terms and definitions	4
4 Principle	4
5 Apparatus and materials	4
5.1 Cleaning cloth	4
5.2 Calibration plates.....	4
5.3 Abrasion paper strips.....	5
5.4 Test apparatus	5
5.5 Balance	5
5.6 Conditioning chamber.....	5
5.7 Diffuse light source	5
6 Preparation and conditioning	6
6.1 Conditioning.....	6
6.2 Test surface.....	6
6.3 Preparation of test surfaces and abrasive paper	6
7 Test procedure	6
7.1 Preparation of abrasive wheels.....	6
7.2 Calibration of abrasive paper	6
7.3 Abrasion of test area	7
7.4 Determination of Initial Wear Point (IP)	7
7.4.1 General.....	7
7.4.2 Foil, laminate and melamine faced boards	8
7.4.3 Pigmented lacquers.....	8
7.4.4 Transparent coatings	8
8 Assessment of results	8
9 Test report	9
Annex A (normative) Calibration and maintenance of abrasion equipment	10
A.1 General	10
A.2 Apparatus	10
A.2.1 Calibration block.....	10
A.2.2 Feeler gauges.....	10
A.2.3 Shim washers.....	10
A.3 Procedure	11
A.3.1 Bearing wear	11
A.3.2 Shaft wear	11
A.3.3 Alignment	11
A.3.4 Alignment – dual head abradar	11
Annex B (normative) Examples of abrasion traces	14
Annex C (informative) Significant technical changes in revised edition of this standard	16
Bibliography	17

Foreword

This document (EN 15185:2011) has been prepared by Technical Committee CEN/TC 207 "Furniture", the secretariat of which is held by UNI.

This European Standard shall be given the status of a national standard, either by publication of an identical text or by endorsement, at the latest by November 2011, and conflicting national standards shall be withdrawn at the latest by November 2011.

Attention is drawn to the possibility that some of the elements of this document may be the subject of patent rights. CEN [and/or CENELEC] shall not be held responsible for identifying any or all such patent rights.

This document supersedes CEN/TS 15185:2005.

Annex C lists the significant changes in the revised edition of this standard.

According to the CEN/CENELEC Internal Regulations, the national standards organizations of the following countries are bound to implement this European Standard: Austria, Belgium, Bulgaria, Croatia, Cyprus, Czech Republic, Denmark, Estonia, Finland, France, Germany, Greece, Hungary, Iceland, Ireland, Italy, Latvia, Lithuania, Luxembourg, Malta, Netherlands, Norway, Poland, Portugal, Romania, Slovakia, Slovenia, Spain, Sweden, Switzerland and the United Kingdom.

1 Scope

This European Standard specifies a method for the assessment of the abrasion resistance of surfaces referred to under 7.4.

It does not apply to leather and textile surfaces.

It does not apply to the surfaces covered by EN 14434.

The test is intended to be carried out on a part of the finished furniture, but can be carried out on test panels of the same material, finished in an identical manner to the finished product, and of a size sufficient to meet the requirements of the test.

The test shall be carried out on unused surfaces.

2 Normative references

The following referenced documents are indispensable for the application of this document. For dated references, only the edition cited applies. For undated references, the latest edition of the referenced document (including any amendments) applies.

EN ISO 6506-1, *Metallic materials – Brinell hardness test – Part 1: Test method (ISO 6506-1:2005)*

ISO 9352, *Plastics – Determination of resistance to wear by abrasive wheels*

3 Terms and definitions

For the purposes of this document, the following terms and definitions apply.

3.1

test surface

part of the test panel

3.2

test panel

panel including the test surface

NOTE It may be cut from a finished item of furniture or it may be a separate panel produced in the same manner as the finished item of furniture.

3.3

test area

part of the test surface under the wheels covered by the abrasion paper strips (5.3)

3.4

colour rendering index (CRI or Ra)

unitless number that specifies how well the colour of an object appears under illumination by a light source compared to a reference light source

4 Principle

The test simulates the ability of the furniture surface under test, to resist abrasive wear-through. Abrasion is achieved by rotating a specimen in contact with a pair of loaded cylindrical wheels covered with abrasive paper. The wheels are positioned so that their cylindrical faces are equidistant from the specimen's axis of rotation but not tangential to it. As they are turned by the rotating specimen they abrade an annular track on the specimen's surface. The number of revolutions of the specimen required to cause one defined degree of abrasion, is used as measurement of resistance to surface wear.

5 Apparatus and materials

5.1 Cleaning cloth

White soft absorbent cloth.

5.2 Calibration plates

Taber S-34¹⁾ or equivalent, having a thickness of $(0,8 \pm 0,1)$ mm and a Brinell hardness of (48 ± 2) when tested in accordance with EN ISO 6506-1, except that the ball diameter shall be 5 mm and the load 360 N.

1) Taber S-34 is the trade name of a product supplied by Taber. This information is given for the convenience of users of this document and does not constitute an endorsement by CEN of the product named. Equivalent products may be used if they can be shown to lead to the same results.

5.3 Abrasion paper strips

Taber S-42²⁾ or equivalent, of width $(12,7 \pm 0,1)$ mm and length about 160 mm, according to the following specification:

- a) paper of grammage from 70 g/m^2 to 100 g/m^2 ;
- b) open coated 180 grit powdered aluminium oxide (Al_2O_3) having a particle size such that it will pass through a sieve of aperture $100 \mu\text{m}$ and remain on a sieve having an aperture of $63 \mu\text{m}$;
- c) adhesive backing.

5.4 Test apparatus

As specified in ISO 9352 with following deviations:

NOTE A suitable machine is available from Taber Acquisition Corp., Taber industries, 455 Bryant St P.O. Box 164, North Tonawanda, NY 14120, USA. This information is given for the convenience of users of this European standard and does not constitute an endorsement by CEN of the machine.

- a) the hardness of wheels' rubber layer shall be between 60 and 70 Shore A, when measured in the middle of the contact surface; make 4 measurements and calculate the average value;

The laboratories shall measure the hardness at least once every 6 months.

- b) weight of loading: every wheel shall apply a force $(5,4 \pm 0,2)$ N on the sample;
- c) vacuum system: the distance between the vacuum suction nozzle (inlet vacuum system) and the test area shall be $(1,5 \pm 0,5)$ mm. The vacuum system shall remove practically all the dust;
- d) the distance between the middle axis of the sample holder and the wheels shall be calibrated according to Annex A.

5.5 Balance

The accuracy of the balance shall be 1 mg.

5.6 Conditioning chamber

A chamber with a standard atmosphere of (23 ± 2) °C, relative humidity (50 ± 5) %.

5.7 Diffuse light source

Light source providing evenly diffused light giving an illumination on the test surface of (1200 ± 400) lx. This may either be diffused daylight or be diffused artificial daylight.

NOTE The daylight should be unaffected by surrounding trees, buildings, etc. When artificial light is used it is recommended that it should have a correlated colour temperature of $(6500 + 50)$ K and a R_a greater than 92, by using a colour matching booth in accordance with EN ISO 3668.

2) Taber S-42 is the trade name of a product supplied by Taber. This information is given for the convenience of users of this document and does not constitute an endorsement by CEN of the product named. Equivalent products may be used if they can be shown to lead to the same results.

6 Preparation and conditioning

6.1 Conditioning

Conditioning of test surface shall begin at least one week before testing and shall be carried out in air at a temperature of (23 ± 2) °C and relative humidity of (50 ± 5) %.

The conditioning time shall be stated in the test report.

Condition the abrasion paper strips at least for one week in the conditioning atmosphere of (23 ± 2) °C and (50 ± 5) % R.H., before testing, see 5.6.

6.2 Test surface

Three test surfaces shall be prepared.

The test surface shall be taken at least 5 mm from the edge of the test panel.

Each test surface shall be a piece of test panel, shaped to fit the type of clamping device used. It shall usually be a square of 100 mm x 100 mm, and including an appropriated hole drilled in the centre to place the test surface in the axis of the apparatus.

The test surface shall be carefully wiped with a cleaning cloth (5.1) before the test.

The test surface shall be substantially flat.

6.3 Preparation of test surfaces and abrasive paper

Using a suitable marker pen, mark the surface of each test surface with two lines at right angles, diagonals, so that the surface area is divided into four quadrants, according to Figure 1.




Figure 1 — Test surface area divided into four quadrants

7 Test procedure

7.1 Preparation of abrasive wheels

Bond a strip of conditioned unused abrasive paper to each of the rubber covered wheels. Ensure that the cylindrical surface is completely covered, but without any overlapping of the abrasive paper.

7.2 Calibration of abrasive paper

Carry out this calibration three times for each box.

Prepare two abrasive wheels, in the correct hardness range (5.4), with conditioned unused strips of abrasive paper.

Clamp a zinc plate in the specimen holder, start the vacuum device, set the revolution-counter to zero, lower the wheels, ensuring that the arms are horizontal and the load on the zinc plate is $(5,4 \pm 0,2)$ N, and abrade the zinc plate for 500 revolutions. Wipe the zinc plate clean and weigh to the nearest 1 mg. Replace the abrasive paper on the wheels with preconditioned unused strips from the same batch, clamp the same zinc plate in the specimen holder, lower the abrasive wheels and operate the suction device. Abrade the zinc plate for an additional 500 revolutions, then wipe it clean and reweigh it to the nearest 1 mg.

Any box containing abrasive paper which causes a loss in mass of the zinc plate which is outside (120 ± 20) mg, for any pair of calibrate strips, shall not be used for testing.

The result (mean value of the 3 calibrations / 120) shall be named "correction factor" and shall be included in the test report.

7.3 Abrasion of test area

Perform the test immediately after removal of the test surface and calibrated abrasive paper from the conditioning atmosphere.

Prepare two wheels, in the correct hardness range, with preconditioned unused abrasive paper from the same box previously approved by calibration. Fit the wheels to the machine and set the revolution counter to zero.

Clamp the test surface in the holder, ensuring that it is placed horizontally. Lower the abrasive wheels on to the specimen, ensuring that the arms are horizontal and the load on the samples is $(5,4 \pm 0,2)$ N. Start the vacuum device for removing practically all the dust, and begin abrading the test area.

NOTE If the arms are not horizontal, then there are two possibilities: to modify appropriately the apparatus or to reduce appropriately the thickness of the test surface before the conditioning, see Clause 6.

Before each assessment, in order to correctly assess the Initial Wear Point (IP), see 7.4, ensure the surface is free of dust. If needed, wipe with the cleaning cloth.

At the beginning of the test, the visual assessment shall be carried out, depending on the expected IP (see 7.4), as follows:

- under 200 revolutions, every 10 cycles;
- over 200 revolutions, every 25 cycles;
- over 500 revolutions, every 50 cycles;
- when close to IP, the assessment shall be carried out every 10 cycles.

Replace the abrasive paper after every 200 revolutions.

Continue the test in this way until the IP is reached. Record the number of revolutions.

7.4 Determination of Initial Wear Point (IP)

7.4.1 General

The determination of IP shall be established by one observer experienced in this type of assessment. In case of a dispute, three observers shall carry out the visual assessment.

The determination of IP shall be carried out under the light described above, see 5.7.

To assess the IP, use the following:

7.4.2 Foil, laminate and melamine faced boards

The first clearly recognisable wear-through of the print, pattern or plain colour appears and the sub-layer becomes exposed in four quadrants.

Compare the examined test surface with the examples for IP points and deviations in Annex B.

The sub-layer for printed patterns is the background on which the pattern is printed; for plain colours it is the first sub-layer of different colour.

7.4.3 Pigmented lacquers

The first clearly recognisable wear-through of the substrate, or layer with other colour, appears in all the four quadrants.

7.4.4 Transparent coatings

The first clearly recognisable wear-through of the varnish becomes exposed in four quadrants.

The following procedure shall be used:

- draw a circle on the abrasion trace by using a marker pen giving a contrast with the sample colour (not waterproof ink);
- if the ink penetrates into the wood grain along the grain direction in any part of abrasion trace, the IP point is nearly reached;
- the IP shall be assessed by using any agent suitable for marking when the wood or wood veneer substrate is exposed, such as a water solution of 0,1% (m/m) methyl blue, or a solution of 1 % (m/m) 1,3,5-trihydroxybenzene (CAS number: 108-73-6) in 10 % (m/m) HCl, (e.g. by mixing 1 g of 1,3,5-trihydroxybenzene in 99 g 10 % HCl). The liquid shall be spread over the surface and removed with a dry paper in order to colour the abraded surface and distinguish it from the not completely abraded surface. In case of using 1,3,5-trihydroxybenzene a contact time of minimum two minutes shall be observed.

Compare the examined test surface with the examples for IP points and deviations described in Annex B.

8 Assessment of results

The abrasion resistance of the test surface shall be expressed as the number of revolutions at which IP is reached.

The test result shall be the mean value of the 3 test surfaces rounded to the nearest 10 cycles.

9 Test report

The test report shall include at least the following information:

- a) reference to this European Standard;
- b) the name, type and if the test surface has been cut in order to get the horizontality of the arms;
- c) conditioning time;
- d) the mean abrasion resistance for the sample under test, in revolutions;
- e) the correction factor;
- f) any deviations from this European Standard;
- g) the name and address of the test facility;
- h) the date of the test.

Annex A (normative)

Calibration and maintenance of abrasion equipment

A.1 General

Calibration and maintenance of the equipment shall be carried out, in order to ensure correct and comparable test results.

The procedures contained in this annex have been developed for the Taber equipment. The principles may, however, be applied to similar equipment.

Three parts have been identified as potential sources of error. Each is addressed separately in this annex; however, each is dependent upon the other. The first source of error is bearing wear, the second is shaft wear and the third is alignment of the arms.

Improper alignment of the abrasive wheels can lead to each wheel abrading a different path from the wheel across the sample as well as the wheels on other machines. The path surface area can differ by as much as 20 % and the area abraded by both wheels on a sample could be less than 50 % of the total abraded area for that sample.

The procedures outlined below do not necessarily address all potential sources of variance.

A.2 Apparatus

A.2.1 Calibration block

Calibration block of preferably steel measuring $(77,90 \pm 0,02)$ mm \times $(77,90 \pm 0,02)$ mm \times $(25,00 \pm 0,02)$ mm with a hole drilled and threaded with UNF $\frac{1}{4}$ inch in accordance with EN/ISO/ANSI in the centre $(38,95 \pm 0,02)$ mm of the $(77,90 \pm 0,02)$ mm \times $(77,90 \pm 0,02)$ mm face such that the block can be threaded onto the holder disc of the abrader. All edges shall be made with a radius of 1 mm.

A.2.2 Feeler gauges

Feeler gauges of various thickness.

A.2.3 Shim washers

Shim washers of various thickness ranging from 0,05 mm and up. The inside diameter shall be 8 mm and the outside diameter shall be 13 mm.

A.3 Procedure

A.3.1 Bearing wear

Examine each arm of the abrader visually and by hand for any bearing wear. Specific areas to examine are the pivot areas of the abrader arm and the shaft on which the wheel revolve. This includes, but is not limited to, any sideways, twisting, or other motion outside the specific rotation of the arm or the shaft. Any movement noted, other than the pivoting of the arm or shaft, requires that further examination be made to determine the cause of the excess movement.

Specific repairs shall be completed before attempting subsequent portions of the procedure.

A.3.2 Shaft wear

In certain instances, the shaft for the abrader wheel may slide end to end. This movement shall be eliminated by placing shim washers of appropriate thickness between the bearing face and the shaft keeper ring on the end of the shaft opposite the abrader wheel mounting. This can be measured using the feeler gauges to measure the gap prior to disassembly and the appropriate thickness of shim washers placed on the shaft.

A.3.3 Alignment

Remove the rubber wheels from their respective shaft mounting and set aside. Remove the rubber mat on the sample table (if used).

Attach the calibration block to the table by the threaded mount (Figure A.1).

Gently lower the arms with the exposed shaft ends onto the block. Rotate the block to square the block with the shaft face of each arm. The face of each shaft shall squarely meet the adjacent face of the calibration block without force and without any gap. If the arm does not seat squarely onto the block or leaves a gap between the face and block, then that arm shall be aligned.

If the alignment does not allow the wheel shaft to rest against the shaft hub and face, the arm shall be moved away from the block by loosening the two set screws on the top of the machine toward the back that holds the shaft on which the arm pivots and moving the entire arm assembly away from the block enough so that the shaft face and hub rest squarely against the calibration block. Retighten the set screws and recheck.

If the alignment leaves a gap between the shaft hub/face and the calibration block, the arm shall be moved toward the block by loosening the two set screws on the top of the machine toward the back that holds the shaft on which the arm pivots and moving the entire arm assembly towards the block enough so that the shaft face and hub rest squarely against the calibration block. Retighten the set screws and recheck.

A.3.4 Alignment – dual head abrader

In the case of a dual head abrader, the alignment is more complex due to the common mount utilized by the shaft holding the interior arms for each side of the abrader. In the case of a dual head abrader, the following order of alignment adjustments is made:

Remove rubber wheels and table mats from both heads and attach the calibration block to the left head.


Check Arm 1 for correct alignment (Figure A.2). If adjustment is required, loosen SS1 and SS2 and move the arm assembly in or out to squarely align the shaft face/hub to the calibration block. Retighten the set screws and recheck.

Check Arm 2 for correct alignment. If adjustment is required, loosen SS3, SS4 and SS5 and move the arm assembly in or out to squarely align the shaft face/hub to the calibration block. Retighten the set screws SS3 and SS4 and recheck.

Remove the calibration block from the left head and attach it to the right head.

Check Arm 3 for correct alignment. SS5 is loose. Seat the shaft beneath SS5 fully to the left and check the Arm 3 alignment. If the shaft face/hub is too tight to the calibration block, shims shall be removed from Arm 3 assembly at the point the shaft seats into the arm at Point X. Part the assembly by moving the Arm 3 and shaft under SS5 fully to the right and remove the shims as needed to squarely place the shaft face/hub against the calibration block. Retighten the set screw SS5 and the shaft face/hub with the feeler gauge to determine the thickness of shim washers to add. Part the assembly by moving the Arm 3 and shaft under SS5 fully to the right and add the shims as needed to squarely place the shaft face/hub against the calibration block. Retighten the set screw SS5 and recheck.

Check Arm 4 for correct alignment. If adjustment is required, loosen SS6 and SS7 and move the arm assembly in or out to squarely align the shaft face/hub to the calibration block. Retighten the set screws and recheck for correct alignment.



Key

- 1 Arm 1
- 2 Arm 2
- 3 Arm 3
- 4 Arm 4
- 5 Calibration block
- 6 Left head
- 7 Right head

Figure A.1 — Dual head abrader with calibration block and identification points

Dimensions in millimetres




Figure A.2 — Calibration block with arms correctly aligned

Annex B
 (normative)

Examples of abrasion traces

Table B.1 — Examples of abrasion traces







Description	Example for abrasion traces on printings
IP is not reached (no abrasion until the print in all 4 quadrants)	
IP is correct (beginning abrasion until the print in all 4 quadrants)	
IP is passed (too many revolutions after abrasion until the substrate)	

Table B.2 — Examples for abrasion traces on varnishes

Description	Example for abrasion traces on varnishes
<p>IP is not reached (no abrasion until the wood surface in all 4 quadrants)</p>	
<p>IP is correct (beginning abrasion until the wood surface in all 4 quadrants)</p>	
<p>IP is passed (too many revolutions after abrasion until the substrate)</p>	

Annex C (informative)

Significant technical changes in revised edition of this standard

Significant technical differences between this document and CEN/TS 15185:2005 are as follows:

- a) inclusion of definition of colour rendering index;
- b) measurement of the hardness of the wheels is included as normative part;
- c) storing of test unit/test panel is deleted;
- d) assessment of Initial Wear Point is split in three subclauses: Foil, laminate and melamine faced boards; pigmented coatings and transparent coatings;
- e) inclusion of a normative annex: Calibration and maintenance of abrasion equipment;
- f) inclusion of a normative annex: Examples of abrasion traces.

Bibliography

- [1] EN ISO 3668, *Paints and varnishes – Visual comparison of the colour of paints (ISO 3668:1998)*
- [2] EN 14434, *Writing boards for educational institutions – Ergonomic, technical and safety requirements and their test methods*

British Standards Institution (BSI)

BSI is the independent national body responsible for preparing British Standards and other standards-related publications, information and services.

It presents the UK view on standards in Europe and at the international level.

It is incorporated by Royal Charter.

Revisions

British Standards are updated by amendment or revision. Users of British Standards should make sure that they possess the latest amendments or editions.

It is the constant aim of BSI to improve the quality of our products and services. We would be grateful if anyone finding an inaccuracy or ambiguity while using this British Standard would inform the Secretary of the technical committee responsible, the identity of which can be found on the inside front cover.

Tel: +44 (0)20 8996 9001 Fax: +44 (0)20 8996 7001

BSI offers Members an individual updating service called PLUS which ensures that subscribers automatically receive the latest editions of standards.

Tel: +44 (0)20 8996 7669 Fax: +44 (0)20 8996 7001

Email: plus@bsigroup.com

Buying standards

You may buy PDF and hard copy versions of standards directly using a credit card from the BSI Shop on the website www.bsigroup.com/shop. In addition all orders for BSI, international and foreign standards publications can be addressed to BSI Customer Services.

Tel: +44 (0)20 8996 9001 Fax: +44 (0)20 8996 7001

Email: orders@bsigroup.com

In response to orders for international standards, it is BSI policy to supply the BSI implementation of those that have been published as British Standards, unless otherwise requested.

Information on standards

BSI provides a wide range of information on national, European and international standards through its Knowledge Centre.

Tel: +44 (0)20 8996 7004 Fax: +44 (0)20 8996 7005

Email: knowledgecentre@bsigroup.com

Various BSI electronic information services are also available which give details on all its products and services.

Tel: +44 (0)20 8996 7111 Fax: +44 (0)20 8996 7048

Email: info@bsigroup.com

BSI Subscribing Members are kept up to date with standards developments and receive substantial discounts on the purchase price of standards. For details of these and other benefits contact Membership Administration.

Tel: +44 (0)20 8996 7002 Fax: +44 (0)20 8996 7001

Email: membership@bsigroup.com

Information regarding online access to British Standards via British Standards Online can be found at www.bsigroup.com/BSOL

Further information about BSI is available on the BSI website at www.bsigroup.com/standards

Copyright

Copyright subsists in all BSI publications. BSI also holds the copyright, in the UK, of the publications of the international standardization bodies. Except as permitted under the Copyright, Designs and Patents Act 1988 no extract may be reproduced, stored in a retrieval system or transmitted in any form or by any means – electronic, photocopying, recording or otherwise – without prior written permission from BSI. This does not preclude the free use, in the course of implementing the standard of necessary details such as symbols, and size, type or grade designations. If these details are to be used for any other purpose than implementation then the prior written permission of BSI must be obtained. Details and advice can be obtained from the Copyright & Licensing Manager.

Tel: +44 (0)20 8996 7070

Email: copyright@bsigroup.com

BSI Group Headquarters

389 Chiswick High Road London W4 4AL UK

Tel +44 (0)20 8996 9001

Fax +44 (0)20 8996 7001

www.bsigroup.com/standards