## BS ISO 8820-4:2010



## **BSI Standards Publication**

## Road vehicles — Fuse-links

Part 4: Fuse-links with female contacts (type A) and bolt-in contacts (type B) and their test fixtures



BS ISO 8820-4:2010 BRITISH STANDARD

#### National foreword

This British Standard is the UK implementation of ISO 8820-4:2010.

The UK participation in its preparation was entrusted to Technical Committee AUE/16, Electrical and electronic equipment.

A list of organizations represented on this committee can be obtained on request to its secretary.

This publication does not purport to include all the necessary provisions of a contract. Users are responsible for its correct application.

© BSI 2011

ISBN 978 0 580 65015 4

ICS 43.040.10

Compliance with a British Standard cannot confer immunity from legal obligations.

This British Standard was published under the authority of the Standards Policy and Strategy Committee on 31 January 2011.

Amendments issued since publication

Date Text affected

# INTERNATIONAL STANDARD

BS ISO 8820-4:2010 ISO 8820-4

Second edition 2010-12-15

## Road vehicles — Fuse-links —

## Part 4:

Fuse-links with female contacts (type A) and bolt-in contacts (type B) and their test fixtures

Véhicules routiers — Liaisons fusibles —

Partie 4: Liaisons fusibles avec contacts femelles (type A) et contacts boulonnés (type B) et leurs montages d'essai



#### PDF disclaimer

This PDF file may contain embedded typefaces. In accordance with Adobe's licensing policy, this file may be printed or viewed but shall not be edited unless the typefaces which are embedded are licensed to and installed on the computer performing the editing. In downloading this file, parties accept therein the responsibility of not infringing Adobe's licensing policy. The ISO Central Secretariat accepts no liability in this area.

Adobe is a trademark of Adobe Systems Incorporated.

Details of the software products used to create this PDF file can be found in the General Info relative to the file; the PDF-creation parameters were optimized for printing. Every care has been taken to ensure that the file is suitable for use by ISO member bodies. In the unlikely event that a problem relating to it is found, please inform the Central Secretariat at the address given below.



#### COPYRIGHT PROTECTED DOCUMENT

© ISO 2010

All rights reserved. Unless otherwise specified, no part of this publication may be reproduced or utilized in any form or by any means, electronic or mechanical, including photocopying and microfilm, without permission in writing from either ISO at the address below or ISO's member body in the country of the requester.

ISO copyright office
Case postale 56 • CH-1211 Geneva 20
Tel. + 41 22 749 01 11
Fax + 41 22 749 09 47
E-mail copyright@iso.org
Web www.iso.org

Published in Switzerland

## Contents

Page	
------	--

Forew	vord	iv
1	Scope	1
2	Normative references	1
3	Terms and definitions	1
4	Marking, labelling and colour coding	2
5 5.1 5.2 5.3 5.4 5.5 5.6	Tests and requirements  General  Test sequence  Test cable sizes  Voltage drop  Transient current cycling  Environmental condition	2 4 5
5.7 5.8 5.9 5.10 5.11 5.12	Operating time-rating Current steps Breaking capacity Strength of terminals Temperature rise Rapid change of temperature with specified transition duration	7 7 7
6 6.1 6.2 6.3 6.4	Dimensions	9 10 11
7 7.1 7.2 7.3	Test fixtures	13 14
Annex	x A (informative) Tab dimensions for fuse-boxes	16

#### **Foreword**

ISO (the International Organization for Standardization) is a worldwide federation of national standards bodies (ISO member bodies). The work of preparing International Standards is normally carried out through ISO technical committees. Each member body interested in a subject for which a technical committee has been established has the right to be represented on that committee. International organizations, governmental and non-governmental, in liaison with ISO, also take part in the work. ISO collaborates closely with the International Electrotechnical Commission (IEC) on all matters of electrotechnical standardization.

International Standards are drafted in accordance with the rules given in the ISO/IEC Directives, Part 2.

The main task of technical committees is to prepare International Standards. Draft International Standards adopted by the technical committees are circulated to the member bodies for voting. Publication as an International Standard requires approval by at least 75 % of the member bodies casting a vote.

Attention is drawn to the possibility that some of the elements of this document may be the subject of patent rights. ISO shall not be held responsible for identifying any or all such patent rights.

ISO 8820-4 was prepared by Technical Committee ISO/TC 22, Road vehicles, Subcommittee SC 3, Electrical and electronic equipment.

This second edition cancels and replaces the first edition (ISO 8820-4:2002), which has been technically revised.

ISO 8820 consists of the following parts, under the general title *Road vehicles* — *Fuse-links*:

- Part 1: Definitions and general test requirements
- Part 2: User's guide
- Part 3: Fuse-link with tabs (blade type) Type C (medium), Type E (high current) and Type F (miniature)
- Part 4: Fuse-links with female contacts (type A) and bolt-in contacts (type B) and their test fixtures
- Part 5: Fuse-links with axial terminals (Strip fuse-links) Types SF30 and SF51 and test fixtures
- Part 6: Single-bolt fuse-links
- Part 7: Fuse-links with tabs (Type G) with rated voltage of 450 V

## Road vehicles — Fuse-links —

## Part 4:

# Fuse-links with female contacts (type A) and bolt-in contacts (type B) and their test fixtures

## 1 Scope

This part of ISO 8820 specifies fuse-links with female contacts (type A) and bolt-in contacts (type B) for use in road vehicles. It establishes, for these fuse-link types, the rated current, test procedures, performance requirements and dimensions.

This part of ISO 8820 is applicable to fuse-links with a rated voltage of 32 V or 58 V, a current rating  $\leq$  140 A and a breaking capacity of 1 000 A intended for road vehicles.

This part of ISO 8820 is intended to be used in conjunction with ISO 8820-1 and with ISO 8820-2. The numbering of its clauses corresponds to that of ISO 8820-1 whose requirements are applicable, except where modified by requirements particular to this part of ISO 8820.

#### 2 Normative references

The following referenced documents are indispensable for the application of this document. For dated references, only the edition cited applies. For undated references, the latest edition of the referenced document (including any amendments) applies.

ISO 6722, Road vehicles — 60 V and 600 V single-core cables — Dimensions, test methods and requirements

ISO 8820-1, Road vehicles — Fuse-links — Part 1: Definitions and general test requirements

ISO 16750-4, Road vehicles — Environmental conditions and testing for electrical and electronic equipment — Part 4: Climatic load

#### 3 Terms and definitions

For the purposes of this document, the terms and definitions given in 8820-1 apply.

## 4 Marking, labelling and colour coding

See ISO 8820-1 and Table 1.

Table 1 — Fuse-link colour coding

Fuse rating A	Colour
20	Light blue
25	White
30	Pink
35	Dark green
40	Green
50	Red
60	Yellow
70	Brown
80	Black
100	Blue
120	White
140	Red-brown

## 5 Tests and requirements

#### 5.1 General

In addition to carrying out the test procedures in accordance with ISO 8820-1 the following criteria shall be observed:


Tests shall be performed following the test sequences in Table 2.

The test fixtures for electrical tests (see Annex A) shall be designed in accordance with Figure 1. The connection resistance shall be for type A  $\leq$  1,0 m $\Omega$  and for type B  $\leq$  0,35 m $\Omega$  to ensure the proper functioning of the test fixture.


Fuse-links in accordance with this part of ISO 8820 shall provide for visible evidence of an open fuse element.

NOTE For measuring the contact resistance of Type A, the body of the fuse-link may require modification or resistance of the fuse element should be subtracted from the one of whole fuse (see Figure 1, points labelled "1").


Dimensions in millimetres



## a) Test fixture for type A1, A1S, A2 and A3



## b) Test fixture for type B1



c) Test fixture for type B2

- 1 measuring points for the voltage drop (see 5.2)
- 2 test fixture
- 3 cable size according to Table 3

Figure 1 — Test schematic

#### 5.2 Test sequence

Table 2 — Test sequence

No.	Test		(Sub-)	Sample groups <sup>a</sup>							
NO.	Tes	Clause	1	2	3	4	5	6	7	8	
1	Dimensions		6	Х	Х	Х	_	_	_	_	_
2	Marking, labelling and	colour coding	4	Х	Х	Х	Х	Х	Х	Х	Х
3	Fuse-link voltage drop		5.4	Х	Х	Х	_	_	_	_	_
4	Strength of terminals		5.10	Х	Х	Х	_	_	_	_	_
		Climatic load		_	_	_	Х	_	_	_	_
5	Environmental conditions	Chemical load	5.6	_	_	_	_	Х	_	_	_
	_	Mechanical load		_	_	_	_	_	Х	_	_
6	Transient current cyclin	5.5	_	_	_	_	_	_	Х	_	
7	Temperature rise	5.11	_	_	_	_	_	_	_	Х	
8	Resistance against temperature shock		5.12	_	_	_	_	_	_	_	Х
9	Fuse-link voltage drop		5.4	_	_	_	Х	Х	Х	Х	Х
10	Current steps		5.8	_	_	Х	_	_	_	_	_
11	Breaking capacity		5.9	Х	_	_	_	_	_	_	_
		1,1 I <sub>R</sub>		_	Х	_	Х	Х	Х	Х	_
		1,35 I <sub>R</sub> or 1,5 I <sub>R</sub>		_	Υ	_	Υ	Υ	Υ	Υ	_
12	Operating time-rating test	2,0 I <sub>R</sub>	5.7	_	Υ	_	Υ	Υ	Υ	Υ	_
		3,5 I <sub>R</sub>		_	Υ	_	Υ	Υ	Υ	Υ	_
		6,0 I <sub>R</sub>		_	Υ	_	Υ	Υ	Υ	Υ	_
13	Strength of terminals		5.10	Х	Х	Х	Х	Х	Х	Х	Х

Each sample group shall contain a minimum of eight fuse-links.

## 5.3 Test cable sizes

Test cable sizes shall be as shown in Tables 3, 4 and 5. All tests for a particular fuse-link rating shall be performed using the same cable size.

Test cable sizes are specified to allow comparative fuse-link tests to be carried out. The cable size specified does not necessarily indicate the size of cable to be used in the vehicle application.

Y For these operating time tests the sample groups 2, 4, 5, 6, 7 and 8 shall be divided equally. These fuses are intended to be subjected to a single operating time test only.

Not required

A1S and A2 Type A I Type B I I II	Length	rea <sup>a</sup>	Conductor cross-sectional area <sup>a</sup> mm <sup>2</sup>					Type A1,	Fuse-link
I     II     I     II       20     X       25     X       30     X       35     X       40     X       50     X       60     X       70     X       80     X    II  II  II  II  II  II  II  II  II	mm	e B	Туре	Type A		Type B	Type A3	A1S and A2	rating A
25 X 30 X 35 X 40 X 50 X X 60 X 70 X 80 X X 2,5 3,0 4,0 3,0 5,0 6,0 5,0 6,0 5,0		II	I	II	ı				
25				2.0	1,5			Х	20
30 X X X X X 3,0 3,0 4,0 3,0 3,0 4,0 3,0 3,0 4,0 3,0 3,0 4,0 5,0 6,0 6,0 6,0 6,0 6,0 6,0 6,0 6,0 6,0 6				2,0	2.5			Χ	25
35 X		3,0	4,0	3.0	2,5	Х	X	Х	30
40     X       50     X       60     X       70     X       80     X          30     X       40     X       5,0     6,0       5,0     6,0       5,0     5,0       6,0     5,0       10,0		<<		3,0	4.0	><		Х	35
60 X X X X 6,0  70 X X 10,0					4,0	Χ		Х	40
60 X X X X 10,0 10,0	500 ± 50	5,0	6,0	5,0	6.0	Χ	X	Х	50
80 X X 10,0	500 ± 50				0,0	Χ	Х	Х	60
80 X X 10,0		0	10	<<		Χ	><	_/	70
		O	10,	0,0	10	Χ	X		80
100 X 16,0 15,0		15.0	16.0			Х		X	100
120 X X		15,0	10,0	<		Х	$\mid \times \mid$		120
140 X 25,0 20,0		20,0	25,0			Х		/ \	140

Table 3 — Test cable sizes

## 5.4 Voltage drop

#### 5.4.1 Tests

The voltage drop  $U_{\mathsf{ab}}$  shall be measured at points labelled "1" across the fuse-link tabs as shown in Figure 1.

## 5.4.2 Requirements

See Table 4.

Table 4 — Fuse-link voltage drop

Fuse-link rating A	Maximum voltage drop mV						
A	A1, A1S	A2, A3	B1, B2				
20	125	180					
25	125						
30		180	140				
35	120						
40	120	180	130				
50		160					
60	115	160					
70							
80		160	120				
100	$1 \times$						
120							
140							


## 5.5 Transient current cycling

#### 5.5.1 Test

See Figure 2 and ISO 8820-1. At an elapsed time of 0,25 s on-time, the current shall fall to a value between 1,25  $I_{\rm R}$  and 1,35  $I_{\rm R}$ . During the first 10 s of each cycle the steady state current shall never fall below 0,5  $I_{\rm R}$ .

## 5.5.2 Requirements

See ISO 8820-1.



## Key

- X time in seconds
- Y rated current
- a One cycle.

Figure 2 — Transient current cycling

#### 5.6 Environmental condition

See ISO 8820-1.

## 5.7 Operating time-rating

#### 5.7.1 Test

See ISO 8820-1.

#### 5.7.2 Requirements

See Table 5.

Table 5 — Operating times

Test current	Operating times s								
A	A1, A1S		A2,	A3	B1, B2				
	min.	max.	min.	max.	min.	max.			
1,10 I <sub>R</sub>	14 400	$\infty$	14 400	$\infty$	14 400	8			
1,35 I <sub>R</sub>	60	1 800							
1,50 I <sub>R</sub>			30	3 600	30	3 600			
2,0 I <sub>R</sub>	2	60	5	100	5	100			
3,5 I <sub>R</sub>	0,2	7	0,2	7	0,2	7			
6,0 I <sub>R</sub>	0,04	1	0,04	1	0,04	1			

### 5.8 Current steps

#### 5.8.1 Test

See ISO 8820-1.

#### 5.8.2 Requirements

See ISO 8820-1.

#### 5.9 Breaking capacity

#### 5.9.1 Test

See ISO 8820-1.

Test at 1 000 A with cable sizes as shown in Table 3.

#### 5.9.2 Requirements

See ISO 8820-1.

After the test, the current through the fuse-link shall not exceed 0,5 mA at the rated voltage.


## 5.10 Strength of terminals

#### 5.10.1 Test for fuse-links of types A1, A1S, A2 and A3

The following force (see Table 6) shall be applied sequentially to each terminal of the fuse-link as shown in Figure 3.

Table 6 — Forces

Fuse-link type	Force in N
A 1, A1S	50 ± 1
A 2	60 ± 1
A 3	00 ± 1



#### Key

F force

Figure 3 — Strength of terminals

#### 5.10.2 Requirements

After the test, the insulator shall be intact and the terminals shall not be bent and/or removed from the insulator.

#### 5.10.3 Test for fuse-links of types B1, B2

Install the fuse-links in the test fixture with the mounting torque according to Table 7. This test is performed without cables and terminals.

Table 7 — Mounting torque and bolt size

Fuse-link type	Mounting torque N·m	Bolt size
В1	6 ± 1	M 6
B2	4,5 ± 1	M 5

NOTE For mounting in the vehicle, the specific procedure (greasing, surface materials, surface roughness, etc.) has to be agreed upon between the fuse manufacturer, the fuse-box manufacturer and the vehicle manufacturer.

#### 5.10.4 Requirement

Fuse-links shall remain physically intact.

#### 5.11 Temperature rise

#### 5.11.1 Test

The temperature rise shall be measured at the temperature-rise measuring point in the standard test fixtures as shown in Annex A after supplying a current equal to  $0,50 I_R$  after the temperature is stabilized.

#### 5.11.2 Requirements

See Table 8.

Table 8 — Temperature rise

Fuse-link rating A	Temperature rise °C
20	
25	
30	
35	50
40	30
50	
60	
70	
80	
100	70
120	70
140	

## 5.12 Rapid change of temperature with specified transition duration

See ISO 16750-4.

The test temperature shall be code J and the temperature holding time is 20 min.

Perform the test for 48 cycles.

#### 6 Dimensions

## 6.1 Fuse-links types A1, A2 and A3

See Figure 4 and Table 9.




Figure 4 — Fuse-link with female contacts A1, A2 and A3

## 6.2 Fuse-links type A1S

See Figure 5 and Table 9.

(\$2,6) (\$2,6) (\$2,5) (\$2,6) (\$2,5) (\$2,6) (\$2,6) (\$2,6) (\$3,6) (\$4,6) Dimensions in millimetres

#### Key

1 represents optional feature

Figure 5 — Fuse-link with female contacts A1S

Table 9 — Fuse-links with female contacts A1, A1S, A2 and A3

Dimensions in millimetres

Dimension	A	<b>A</b> 1		A1S		.2	A3	
Difficusion	Value	Tolerance	Value	Tolerance	Value	Tolerance	Value	Tolerance
а	13,45	±1,15	13,45	±1,15	22,0	±0,5	22,25	±0,75
b	11,75	±0,75	11,75	±0,75	15,2	±0,5	15,25	±0,55
С	11,85	±0,35	11,85	±0,35	15,7	±0,5	18,55	±0,25
d	9,8	±0,3	9,8	±0,3	12,5	±0,5	13,6	±0,3
е	5,5	±0,1	5,5	±0,1	9,0	±0,2	12,4	±0,1
f		_		_	1,55	±0,35		_
g		_		_	10,9	±4,1		_
h	18,1	±0,8	13,75	±0,55	14,5	±0,5	21,3	±1
i	27,0	±0,5	16,0	±0,5	30,75	±1,25	31,0	±0,5

Not applicable.

NOTE These values are for fuse-links only.

## 6.3 Fuse-links types B1 and B2

See Figures 6 and 7, and Table 10.




Figure 6 — Fuse-link with bolt-in contacts B1




Figure 7 — Fuse-link with bolt-in contacts B2

Table 10 — Fuse-links with bolt-in contacts B1, B2

Dimensions in millimetres

Dimension	В	1	B2			
Dilliension	Value	Tolerance	Value	Tolerance		
а	21,95	±0,45	21,95	±0,45		
b	15,05	±0,35	15,05	±0,35		
С	15,0	±0,1	36,0	±0,5		
d	12,0	±0,2	12,0	±0,2		
e	23,6	±1,1	20,50	±1,5		
f	40,15	±3,55	47,6	±0,9		
g	6,5	±0,2	7,5	±0,3		
h	11,5	±0,2	5,4	±0,2		
NOTE The	se values are for fuse-links onl	y.				

## 6.4 Designation

A fuse-link Type A1 in accordance with this part of ISO 8820 for a nominal current of 25 A is designated as follows:


Fuse-link ISO 8820 - A1 - 25

## 7 Test fixtures

## 7.1 Test fixture for fuse-links types A1, A1S, A2 and A3

See Figure 8 and Table 11.

Dimensions in millimetres



- 1 terminal for fuse-link connection (made of copper alloy)
- 2 temperature measuring point (thermocouple)
- 3 voltage drop measuring point (millivolts)
- 4 terminal size
- 5 fixture body

Figure 8 — Test fixture for fuse-links types A1, A2 and A3

Table 11 — Dimensions (in millimetres)

Туре	<i>a</i> ±0,1	<i>b</i> ±0,1	<i>C</i> +0,2 0	d	t
A1	5,5	6,3	10,2	17,2	0,8 +0,04 -0,03
A1S	3,3		8,4		
A2	9,0	8,0	15,5	18,0	
А3	12,4	9,5	14,5	19,8	$1,2 \pm 0,03$

## 7.2 Test fixture for fuse-links type B1

See Figure 9 and Table 12.

Dimensions in millimetres

3

4

6

50

13,8

6

6

100

120

- 1 terminal for fuse-link; plate thickness (0,8  $\pm$  0,04) mm
- 2 temperature measuring point (thermocouple)
- 3 voltage drop measuring points (millivolts)


- 4 terminal size
- 5 screw, washer and nut M6
- 6 fixture body

Figure 9 — Test fixture for fuse-links with bolt-in contacts B1

## 7.3 Test fixture for fuse-links type B2

See Figure 10 and Table 12.

Dimensions in millimetres



- 1 temperature measuring point (thermocouple)
- 2 voltage drop measuring points
- 3 fixture body
- 4 terminal for fuse-link; plate thickness (0,8  $\pm$  0,04) mm

Figure 10 — Test fixture for fuse-links with bolt-in contacts B2

Table 12 — Recommended mounting torque


Fuse-link type	Recommended mounting torque N·m		
B1 – M6 bolt	6 ± 1		
B2 – M5 bolt	4,5 ± 1		


# Annex A (informative)

## Tab dimensions for fuse-boxes

## A.1 Tab dimensions for fuse-boxes

See Figure A.1 and Table A.1.








Figure A.1 — Tab dimensions for fuse-boxes

Table A.1 — Dimensions (in millimetres)

Туре	Dimension						
	а	t	l	b	c		
<b>A</b> 1		$0.8 \pm 0.03$	$0.5\pm0.3$	6,3 ± 0,1	10,3 ± 0,1		
A1S	5,5 ± 0,1				$9.0 \begin{array}{c} +0.2 \\ -0.6 \end{array}$		
A2	9,0 ± 0,2			8,0 <sup>+0,1</sup> <sub>-0,5</sub>	15,5 <sup>+0,2</sup>		
A3	12,4 ± 0,1	1,2 ± 0,03	0,5 ± 0,2	9,5 ± 0,1	15 ± 0,5		



# British Standards Institution (BSI)

BSI is the national body responsible for preparing British Standards and other standards-related publications, information and services.

BSI is incorporated by Royal Charter. British Standards and other standardization products are published by BSI Standards Limited.

#### About us

We bring together business, industry, government, consumers, innovators and others to shape their combined experience and expertise into standards -based solutions.

The knowledge embodied in our standards has been carefully assembled in a dependable format and refined through our open consultation process. Organizations of all sizes and across all sectors choose standards to help them achieve their goals.

#### Information on standards

We can provide you with the knowledge that your organization needs to succeed. Find out more about British Standards by visiting our website at bsigroup.com/standards or contacting our Customer Services team or Knowledge Centre.

#### **Buying standards**

You can buy and download PDF versions of BSI publications, including British and adopted European and international standards, through our website at bsigroup.com/shop, where hard copies can also be purchased.

If you need international and foreign standards from other Standards Development Organizations, hard copies can be ordered from our Customer Services team.

#### **Subscriptions**

Our range of subscription services are designed to make using standards easier for you. For further information on our subscription products go to bsigroup.com/subscriptions.

With **British Standards Online (BSOL)** you'll have instant access to over 55,000 British and adopted European and international standards from your desktop. It's available 24/7 and is refreshed daily so you'll always be up to date.

You can keep in touch with standards developments and receive substantial discounts on the purchase price of standards, both in single copy and subscription format, by becoming a **BSI Subscribing Member**.

**PLUS** is an updating service exclusive to BSI Subscribing Members. You will automatically receive the latest hard copy of your standards when they're revised or replaced.

To find out more about becoming a BSI Subscribing Member and the benefits of membership, please visit bsigroup.com/shop.

With a **Multi-User Network Licence (MUNL)** you are able to host standards publications on your intranet. Licences can cover as few or as many users as you wish. With updates supplied as soon as they're available, you can be sure your documentation is current. For further information, email bsmusales@bsigroup.com.

#### **BSI Group Headquarters**

389 Chiswick High Road London W4 4AL UK

#### **Revisions**

Our British Standards and other publications are updated by amendment or revision.

We continually improve the quality of our products and services to benefit your business. If you find an inaccuracy or ambiguity within a British Standard or other BSI publication please inform the Knowledge Centre.

## Copyright

All the data, software and documentation set out in all British Standards and other BSI publications are the property of and copyrighted by BSI, or some person or entity that owns copyright in the information used (such as the international standardization bodies) and has formally licensed such information to BSI for commercial publication and use. Except as permitted under the Copyright, Designs and Patents Act 1988 no extract may be reproduced, stored in a retrieval system or transmitted in any form or by any means – electronic, photocopying, recording or otherwise – without prior written permission from BSI. Details and advice can be obtained from the Copyright & Licensing Department.

#### **Useful Contacts:**

#### **Customer Services**

Tel: +44 845 086 9001

Email (orders): orders@bsigroup.com
Email (enquiries): cservices@bsigroup.com

#### Subscriptions

Tel: +44 845 086 9001

Email: subscriptions@bsigroup.com

#### Knowledge Centre

Tel: +44 20 8996 7004

Email: knowledgecentre@bsigroup.com

#### **Copyright & Licensing**

Tel: +44 20 8996 7070 Email: copyright@bsigroup.com

